

### Fine stoneware

#### Definition

Fine stoneware with a rough or polished surface

#### Ecology

The recommended products were specially developed for the requirements of natural and artificial stone. Quality, effectiveness and environmental protection have been optimized in relation to one another and in accordance with the latest developments in technology. Please apply the product to a suitable sample area in order to establish its effectiveness, the right dilution, the coverage and its exact effect.

#### Safety

The products comply with the provisions laid down by the law in terms of their labelling and the contained substances. The cleaning agents are registered with the Federal Office for Environment Protection (Umweltbundesamt) in Berlin.

#### Requirements

The floor covering may not be warm on account of sunlight or any other heat source. Accordingly, underfloor heating should be switched off well in advance. Before the stone is provided with a protective coating, the covering must be completely dried out and the residual moisture less than 5%. The following rule of thumb applies for the drying period, depending upon the weather conditions and the object at hand: in a thin bed approx. 2-3 weeks, in a mortar bed approx. 4-6 weeks after laying; after cleaning, on the next day at the earliest.

**Please pay attention to the information on the product labels and the instructions for use on the specification sheets as well.**

#### Cleaning

initial cleaning/building dirt concrete film	<a href="#">AKEMI®'s Ceramics Cement Film Remover</a>	approx. 50-100 m <sup>2</sup> /litre
normal dirt	<a href="#">AKEMI®'s Ceramics Intensive Cleaner</a>	approx. 50-100 m <sup>2</sup> /litre
dirt layers	<a href="#">AKEMI®'s Ceramics Intensive Cleaner</a>	approx. 50-100 m <sup>2</sup> /litre
wax/polymer layers	<a href="#">AKEMI®'s Ceramics Intensive Cleaner</a>	approx. 50-100 m <sup>2</sup> /litre
calcareous-/soap scum (bathroom/shower cab)	<a href="#">AKEMI®'s Disinfectant Cleaner</a>	approx. 100-200 m <sup>2</sup> /litre
joint-cleaning		

#### Protection - indoors + outdoors

impregnation	<a href="#">AKEMI®'s Ceramics Protector W (water basis)</a> water, grease and oil repellent	approx. 10-30 m <sup>2</sup> /litre
--------------	--	-------------------------------------

#### Care

regular cleaning	<a href="#">AKEMI®'s Ceramics Care Cleaner</a> - cares and protects in one step -	approx. 1000-2000 m <sup>2</sup> /litre
------------------	--	---

Your authorized dealer:



# AKEMI®

*Das Original  
in Sachen Stein!*